



### HSM - HELMAC SCALE MANAGEMENT



Software for the complete management of the Helmac scale from PC.

Scales and solutions for retail

### **FUNCTIONS**

- Complete configuration of the scale from PC and management of the system and the connections to external devices (labeller, printer, keyboard, etc.).
- Transmission and storage of all the data processing by the Helmac scale.
- Totalisation function on the data acquired from the scale.

#### Programming and backup of the DATABASES

- PLUs
- PLU groups
- Operators
- VAT rates
- Tares
- Traceability
- Ingredients
- Advertising
- Heading
- Payment types

#### Programming and backup of the scale SETTINGS

- Operational: use, cash registers, advertising, cash management and customer management.
- Ticket and Price computing mode.
- Communication: type of connection to the local network, to PC and external devices such as cash registers, bar code reader etc.
- Keyboards, Password and Hot Keys.

#### TOTALS

- Hourly and daily totals.
- Database of monthly and annual totals.
- Grouping data by: articles, PLU groups, operators, VAT rates, types of payment.

## DETAIL 1

Base Dati e S	ettings				
Base Dati			Settings		
<b>B</b>	10000 1000	and a second	2	9 <sup>2</sup> 9	
Operatività	Scontrino	Peso / Prezzatrice	Stampante	Comunicazioni	
		$\boldsymbol{\mathscr{S}}$	<b>R</b>		
Tastiera	Tastiera Esterna	Password	Tasti Rapidi		

	Calcolati · I		Calcolati - II	Orari
		<u>8</u>	6 🦻	-
PLU G	ruppi PLU	Operatori	Aliquote IVA	Pagamenti

Programming and backup of the scale settings

Management of the department totals

# DETAIL 2



www.helmac.com



#### HEAD OFFICE

Via della Fisica, 18 41042 Spezzano di Fiorano (MO) • Italy Tel.: +39 0536 070960

#### WAREHOUSE

Via della Fisica, 15 41042 Spezzano di Fiorano (MO) • Italy

SALES AND TECHNICAL ASSISTANCE SERVICE

All the specifications and images can be subject to variations and upgrades without prior notice.